

# ANCHORLIFT

## DIRECT

Check measurements on template prior to drilling

**Important:** When printing template be sure your printer is set to actual size

Barracuda 600 & 900 Series

